

Removing Customized Segments



This is how to remove a customized joint.



A manikin must be created or imported to complete the following procedures.



Customizing Joints

1. Select the Customized Joint 
2. The Customized segments for preferred angles dialog box appears.
3. Select the body elements required, which activates the Remove button.
4. Click the Remove button, and Close.

