

---

---

# IBM XIV Storage XIV Top v2.4.2b

## Release Notes

February 25, 2010

For the latest revision of this document, please check the download section at:  
<http://www.ibm.com/systems/support/storage/XIV>

---

---

### XIV GUI Platform Requirements:

|                        |   |
|------------------------|---|
| OS:                    | Windows 2000, Windows ME, Windows XP, Windows Server 2003, Windows Vista, Windows 7, Windows 2008 |
| CPU:                   | 32 bit Dual Core or equivalent, 64 bit  |
| OS:                    | Linux (Red Hat 5.x or equivalent)   |
| CPU:                   | 32 bit, 64 bit  |
| OS:                    | AIX 5.3, AIX 6.1  |
| CPU:                   | PPC   |
| OS:                    | Solaris v9, Solaris v10   |
| CPU:                   | Sparc 32 bit, X86 64 bit  |
| OS:                    | HPUX 11i v2, HPUX 11i v3  |
| CPU:                   | PA-RISC   |
| HD:                    | 100MB Free  |
| Memory:                | 512MB RAM (1GB RAM and above recommended)   |
| Monitor Resolution:    | 1024x768 (Recommended: 1024x768 - 1920x1200)  |
| Monitor Color Quality: | 24/32 True Color Recommended  |

### Installation:

|                     |   |
|---------------------|---|
| Windows:            | Download the GUI installation file, double click it and follow the instructions on the screen   |
| Linux:              | Download the GUI installation package and extract the files in it to a designated folder on your system, using the following command:<br><pre>tar xzf &lt;filename.tar.gz&gt;</pre> |
| Solaris, HPUX, AIX: | Download the GUI installation package.<br>In order to unzip the package you will need the GNU Unzip utility (gunzip), available from  |

|  |   |
|--|---|
|  | <p><a href="http://www.gzip.org/">http://www.gzip.org/</a>.</p> <p>Unzip the package using the following command:<br/>gunzip &lt;filename.tar.gz&gt;</p> <p>Extract the files from the unzipped file to a designated folder on your system, using the following command:<br/>tar xvf &lt;filename.tar&gt;</p> |
|--|---|

## XIV System Requirements:

|                 |                                   |
|-----------------|-----------------------------------|
| R2, R2.1, R2.2: | Code level 10.0.x, 10.1.x, 10.2.x |
|-----------------|-----------------------------------|

## 1 What's New

### 1.1 XIV Top Version 2.4.2b

None

### 1.2 XIV Top Version 2.4.2

- 1.2.1 XIVTop statistics are now shown in MBps for throughput and milliseconds for latency [UI-5539]

### 1.3 XIV Top Version 2.4.1

- 1.3.1 New design, matching the look and feel of the XIV GUI
- 1.3.2 XIV Top now displays an activity graph showing collected statistics from the past 60 seconds
- 1.3.3 XIV Top allows monitoring for Volumes and Hosts simultaneously

## 2 Bug Fixes

None.

## 3 Known Issues and Limitations in Version 2.4.2b

### 3.1 XIV Top Issues:

- 3.1.1 **Issue:** When adding a new system to the GUI, if XIVTop is already running, the new system will not be seen in XIVTop [UI-2417]  
**Resolution:** Restart XIVTop to view the updated list of monitored systems
- 3.1.2 **Issue:** Demo mode is not supported in XIV Top  
**Resolution:** None.